



SECURITY NUT KIT

CONTENTS

- (2) 1/4" 20 SPANNER NUT
- (4) 1/4" WASHERS
- (1) 1/4" HEX NUT BOLT

To Install - Remove Nylock nut and discard (Remember to re-install the Delrin Bushing if it came off the light). Re-install light into aftermarket tabs, cradle, or adjustable clamps. Depending on thickness of tab or clamp, use 1 or 2 washers on each end. Start the Spanner Nut and tighten down with spanner bit.

BE SURE TO RE-CHECK TIGHTNESS PERIODICALLY

IS-40281

1-855-760-LEDS (5337)

RIGIDINDUSTRIES.COM